

KC41 and KC42 Fitting Instructions

FAILURE TO FOLLOW THESE INSTRUCTIONS CAN LEAD TO PREMATURE PRODUCT FAILURE.

The CDA Group Ltd cannot be held responsible for injuries or losses caused by incorrect use or installation of this product. Please note that CDA reserve the right to invalidate the guarantee supplied with this product following incorrect installation or misuse of the appliance or use in a commercial environment.

Over Mounting

1. Place the paper template provided carefully into the correct position on the worktop.
2. Cut along the over mount line until the central section of the worktop comes out.
3. Use clear silicone to seal the cut that has been made; liberally spread the silicone onto the area of the worktop directly adjacent to the hole you have made to the width of the sink rim that it will come into contact with.
4. Repeat step 3 on the under side of the sink rim itself on the surface that will come into contact with the worktop.
5. Carefully position so that you avoid unnecessary readjustment of the sink at the moment of contact.
6. Press down firmly and hold in position for at least 5 minutes applying an even pressure.
7. Ensure the sink is fully sealed and the joint is waterproof by squeezing residual silicone out from along the line of the joint.
8. Do not use the sink for at least 24 hours once fitted.
9. After 24 hours check to ensure the seal is waterproof.

Under Mounting

1. Place the paper template provided carefully into the correct position on the worktop.
2. Cut along the under mount line until the central section of the worktop comes out.
3. Finish the worktop cut out edge to the desired standard.
4. Turn the worktop upside down on a flat, stable surface. Note this will need to be left in position for 24 hours.
5. Spread clear silicone liberally on the glazed surface on the rim of the sink ensuring no areas are left uncovered.
6. Spread clear silicone liberally on the underside of the worktop to the corresponding area where the rim of the sink will be in contact.
7. Press the sink down into the required position firmly for at least 5 minutes applying even pressure. Position a weight on the sink to keep it in place.
8. Ensure the sink is fully sealed and the joint is waterproof by squeezing residual silicone out from along the line of the joint.
9. Do not use the sink for at least 24 hours.
10. 3 metal brackets are provided which should be fixed along the front edge and one on each side; the edge of the bracket overlaps the sink rim and the other edge fixes to the worktop. If a stone/granite worktop is being used wooden blocks can be used to affix the clips to secure the sink; these should be fixed with an epoxy-type adhesive (follow manufacturers' instructions for Epoxy adhesive use).

